



Air Guide Installation Instructions - 96-00 Civic EK - P/N HDP5-02

1. Jack up car and place on jack stands
2. Remove plastic engine underbody cover, trim as required, and then re-fit.
3. Assemble air guide mounting bracket to lower control arm on either side of the vehicle
 - Start by sliding bolts through clamp plate, longer bolt should be on inboard side
 - Position clamp plate above cutout in lower control arm, allow bolts to hang to bottom side
 - Offer up air guide brackets in orientation shown. The folded part should point upwards.
 - Align bolts with holes in air guide bracket and push bracket against lower control arm. The large guide mounting plate goes on the lower side of the control arm.
 - Fit nuts and bolts
 - Tighten bracket hardware lightly so that the bracket is held firm against lower control arm but can still be adjusted
4. Fit air guide to air guide bracket
5. Adjust angle of air guide such that mounting face of air guide is perpendicular to vehicle centreline, and such that air guide is protruding into the free stream below the vehicle with sufficient ground clearance. Recommended distance from ground to the lowest point of the air guide is 70-80mm. Check that air guide is not fouling any suspension parts by turning the steering from lock to lock.
6. Tighten all hardware
7. Lower car off jack stands

Reference Images



*Old bracket design shown above



