



<b>No.</b>	<b>Description</b>	<b>Quantity</b>
1	M12 Tow Hook Weldment	1
2	M12 Flat Washer	3

## **Installation Guide**

- 1. Locate and open the OE tow hook mounting location cover**
- 2. The cover can be removed from the bumper by squeezing it's retaining line barb and pulling it through the retaining loop**
- 3. Clean out the female threads on the chassis side, we recommend running a M12x1.75 tap down the hole to clean the threads, if you don't have one of these available; apply a lubricant to the Honed tow hook and wind in and out of the threaded hole a couple of times.**
- 4. Use the handle of tool like a hammer through the eyelet hole to make it easy to turn the tow hook**
- 5. We provide three washers to help you orientate the eyelet loop when the tow hook is tight. You may need to remove or add washers depending on your preference (if you want the eyelet to be horizontal or vertical when tight).**