



No.	Description	Quantity
1	M18 Tow Hook Weldment	1
2	M18 Spacer	1

Installation Guide

1. Locate and open the OE tow hook mounting location cover
2. The cover can be removed from the bumper by squeezing it's retaining line barb and pulling it through the retaining loop
3. Clean out the female threads on the chassis side, we recommend running a M18x2.5 tap down the hole to clean the threads, if you don't have one of these available; apply a lubricant to the Honed tow hook and wind in and out of the threaded hole a couple of times.
4. Use the handle of tool like a hammer through the eyelet hole to make it easy to turn the tow hook

Note

- The provided spacer is currently known to be required for installing this tow point on the front of AUDM GE8 Jazz.